Table of Contents

IH: Engine Control - Sub-01A	. 1
Battery Ignition (circuit breaker/timer)	. 1
External Circuit Breaker (57-70)	. 1
Contact Points	
Single Contact Points - Manual Advance	
Single Contact Points - Auto Advance	
Dual Contact Points	
Setting / Adjusting Point Gap	
Setting /Adjusting Ignition Timing	. 4
Manual Advance Single Point Circuit Breaker	
Auto Advance Single Point Circuit Breaker	
Manual Advance Dual Point Circuit Breaker	
Internal Circuit Breaker (71-78)	. 4
Roll Pin	. 5
Ignition Timing	. 5
Setting Ignition Timing with a Cigarette Paper	. 5
Setting Points Gap	
Timing Adjustment	. 5
Troubleshooting	. 7
Auto Advance / Breaker Weight Springs	. 7
Circuit Breaker Cam	. 8

t	echtalk:ih:engctl01a http	://www.sportsterpedia.	com/doku.php/techta	lk:ih:engctl01a
---	---------------------------	------------------------	---------------------	-----------------

Last update: 2023/12/31 17:31

Go To Technical Menu

IH: Engine Control - Sub-01A

Battery Ignition (circuit breaker/timer)

57-78 Sportsters (except XLC and XLCH)

- The circuit breaker ignition system has two circuits; (1)-the primary and (2)-the secondary circuits.
- 1. The primary circuit includes the battery, switch, primary coil and the breaker points.
- 2. The secondary circuit consists of the secondary coil and the spark plugs.
- The breaker cam and contact points open and close the low tension circuit between the battery and the ignition coil.
 - (which causes the coil to produce high voltage discharge to the spark plugs)
- The circuit breaker also times the discharge for proper engine firing.

External Circuit Breaker (57-70)



- The circuit breaker ignition was not factory installed on XLCH engines.
- However, they provide consistent lighting for riding at night.
- The magneto has been changed out to a circuit breaker ignition on many XLCHs

Circuit breaker ignition on a 70 model XLCH $^{ m 4)}$



- You've got 2 sets of gears that turn the circuit breaker.
 - The pinion turning the cam gear.
 - Then the cam gear turning the circuit breaker (distributor).
 - Each gear set has to have a certain amount of looseness or backlash.
 - Then the cam and the distributor shaft run in bushings (which can suffer wear.
 - The cam also gets affected by the fact it's also opening and closing a valve.
 - If you've got advance weights, they and the point cam can become sloppy.
 - So there's a lot that can contribute to the timing jumping around.

Contact Points

Single Contact Points - Manual Advance


A single contact point circuit breaker is operated by a cam with a narrow lobe and a wide lobe. ⁶⁾

- 1. The narrow lobe times the front cylinder.
- 2. The wide lobe times the rear cylinder.
- A single ignition coil fires both spark plugs at the same time.
 - One cylinder on compression stroke, firing the combustion gas creating the power stroke.
 - The other cylinder through the exhaust stroke (wasted spark).

2024/01/01 17:28 3/11 IH: Engine Control - Sub-01A

 The non-firing plug will run at the same temperature as the firing plug as long as they're all the same heat range.

- If the firing plugs aren't building up carbon, the "spares" shouldn't either.
- A spark plug's running temperature/heat range isn't correlated to being connected to the coil.
- Timing is advanced or retarded by manually rotating the circuit breaker base in relation to the breaker cam.



Single Contact Points - Auto Advance

The single set of points are operated the same way as the manual advance (by a cam with a narrow lobe and a wide lobe) with the addition flyweights.

(the spark timing cam is advanced automatically with engine speed) 9)

- 1. The narrow lobe times the front cylinder.
- 2. The wide lobe times the rear cylinder.
- A single ignition coil fires both spark plugs at the same time.
 - One cylinder on compression stroke, firing the combustion gas creating the power stroke.
 - The other cylinder through the exhaust stroke.
- Timing is advanced or retarded with an increase or decrease of engine speed by the action of the flyweights.

Dual Contact Points

Two independent sets of points are operated by separate cam lobes (each having it's own cam).

- Each breaker cam opens the points individually which fires to the alternate cylinders with every revolution of the crankshaft
- Dual ignition coils (one for each spark plug) fire each cylinder independently.
- Timing is advanced or retarded by the breaking of each set of points by the single lobe cam on the

timer shaft.

Setting / Adjusting Point Gap

Point gap should be set before ignition timing adjustments. Incorrect point gap spacing will affect timing.

Single Contact Point Circuit Breaker. 12)

Point gap spacing should be exactly .020" (measured with a feeler gauge) when the fiber cam follower is on the highest point of the cam.

- Loosen the points lock down screw and use the eccentric adjusting screw to move the point gap to the correct setting.
- Tighten the lock down screw and re-check the gap, repeat if it moved.

Dual Contact Point Circuit Breaker. 13)

Point gap spacing should be exactly .022" (measured with a feeler gauge) when the fiber cam follower is on the highest point of the cam.

Check ignition timing whenever dual points are adjusted.

Any change in the rear point gap affects timing.

- Front (marked with an "F") and rear points are adjusted separately.
- Loosen the front lock down screw and use the eccentric adjusting screw to move the point gap to the correct setting.
- Tighten the lock down screw and re-check the gap, repeat if it moved.
- Then repeat the procedure for the rear points.
- Both point gaps should have the same gap spacing.

Setting /Adjusting Ignition Timing

Manual Advance Single Point Circuit Breaker

Auto Advance Single Point Circuit Breaker

Manual Advance Dual Point Circuit Breaker

Internal Circuit Breaker (71-78)

Roll Pin

Setting Ignition Timing with a Cigarette Paper


AKA "split pins". These are hollow pins that have a split in them and are held in holes by their own spring tension. 14)

Also, see this video on setting the timing ²²⁾

This passible done a with 0480 strubley lights bring row winther printing while tightening everything up. 15)
This also the orlin to be a week ticaim open provides she appeared that they with the base again to reserve the lighted correlation for the cam.

It'll install both parksplikgs loist bouroaks bure inos therewill from the spasses correctly. ¹⁶⁾
If the from our plicing to the appropriate and a provide the weakly will are the family of the provide the control of the control o

If the bike will backfire, spit and cough very badly with the cam plate adjusted, **Setting Points Gap** Check for missing, bent or destroyed roll pins on the plate. ¹⁸⁾



Timing Adjustment

First, set the front cylinder on the compression stroke.
 You can watch for both front push rods to become bottomed out ²⁷⁾ (collapse the push rod tubes to see the push rod action)
 See also Using the finger method to find the compression stroke and Using a TDC Whistle to find the compression stroke.

- Next, remove timing hole plug from the left crankcase.
 Put the front cylinder advance timing mark in the center of the hole while still on the compression stroke.
- This sets the front piston at 40° before Top Dead Center (TDC) on the compression stroke. (where the spark occurs when the engine is revving at high revs, with the auto advance unit at full advance).

Front flywheel timing mark in inspection window. Front cylinder on compression stroke. 28)



Rear flywheel timing mark in inspection window. Rear cylinder on compression stroke. 29)



- Then leaving the engine in that position with the flywheel line in the middle of the inspection hole, go back around to the points.
- Now, it is time to get out the cigarette paper and do the circuit breaker points static timing.
- Tear the cigarette paper in half lengthways and insert it between the points. They will need nudging open with your finger to get the paper in there.
- The object is to position the points so that they are just opening at the full advance position. Pull gently on the paper, which is held firm by the points.
- You can use a 12mm wrench, or pliers, and turn the points cam counter-clockwise.
- When you feel the points cam hit the end of its movement, the cigarette paper should just come lose and start to slide, with a bit of drag, out of the points.
- If it sticks there, or slips out before the points cam reaches the full advance position and stops, adjust the points backing plate to move the points to the right position.

Cigarette paper in place, spanner to turn points cam to full advance. 30)

This screw, and the one at the top, anchor

backing plate and must be loosend to adjust and timing. 31)

Then, lever the whole backing plate a fraction back or forth using this notch for your screwdriver

then tighten up the locking screws when your done. 32)







- It might take a few tries to get it.

 (so the paper pulls loose as the points cam hits the full advance stop and the timing mark is in the middle of the window).
- Then, check the points gap again and if it is too far out, repeat the whole process until it's right.
- Then, bolt the condenser in back into position.
- When the timing is done for the front cylinder, the rear cylinder timing should also be spot on.
- However, with worn or mismatched parts, this might not be the case.
- This process can be repeated for the rear cylinder (on compression stroke).

7/11

Troubleshooting

2024/01/01 17:28

- If your advance cam will not move, you need to take a look at the advance unit in behind the point plate. 33)
 - It may be damaged or froze up.
- Point gap should be the same between the large and small cam lobes. 34)
 - If point gap exceeds .004" between them, the cam lobe is running eccentric and it should be corrected.
 - Loosen the center bolt and reposition the advance weight assembly toward the widest point gap to equalize the gap. ³⁵⁾

Auto Advance / Breaker Weight Springs

- Starting on January 3, 1969, the MoCo changed the size of the wire of the two ignition timer weight springs on Electra Glide and Sportster models to increase the speed at which timing advance occurred. This was to insure that the spark timing would be fully retarded at cranking speed and will advance gradually as RPMs increase to the fully advanced position. 36)
- Auto advance 1st appeared on the 1965 XLH. It was also used on the 1966 XLH also. 37)
- For 1967 models, the advance mechanism got changed to the familiar setup and a tach drive was added. 38) 39)
- The -67 ones allow for better low speed around town manners, but they allow a little more 'kickback' than the -69 when hot starting using the button. 401 411
- The black -70 springs in these timers don't seem to work nearly as good as when using either -67 or -69.

1967-1968 XLH	32605-67 u			
1969-1970 XLH	32605-69 using (0.016" wire) - fully advanced at 900 RPM 44)			
1970 XLCH	32003-09 u			
1971-1979 XLH / XLCH 32605-70 ⁴⁵⁾				
The 1969 spring is dirty, not black 46)		Both have 10 coils 47)		

Last update: 2023/12/31 17:31



- Before checking ignition timing, remove the circuit breaker plate nuts and plate cover to make sure
 the flyweights will move freely. The cam must return back to retarded position when the engine is
 stopped. If it doesn't retard fully, it usually causes failure of the starter drive. 48)
- Also, on 1967 and later models, make sure that the bent end of the flyweight spring is hooked through the bottom hole and the upper loop grips the retaining groove in the pin tightly.
- Replace the breaker plate cover and set the point gap at 0.020" before checking / setting the advance timing. ⁵⁰⁾

Circuit Breaker Cam

The circuit breaker cam, or ignition timer cam, (newly designed for the 1971 model year) was redesigned for the 1972 model year and was recommended as a replacement for parts order on 1971 model Sportster, Electra Glide and Super Glide models. The 1971 (32542-70) cam had a more rounder profile while the 1972 cam (32542-70A) was more radical with sharper corners at the sides with a flat or straight edge ascend to the cam top center from each side. The 1972 cam allowed greater range in point gap adjustment making (the adjustment less critical) and timing more consistent from cylinder to cylinder. Point gap specs remained the same between the two cams but the dwell changed from 90° to 140° with the '72 cam.

Ignition Tin	ner Cam	
1965-1970	XLH	32542-64A
1970	XLCH	32542-64A
1971	XLH/XLCH	32542-70 (original)
1971-1978	XLH/XLCH	32542-70A (new design)

Go To Technical Menu

1) 6) 9) 10)

1959-1964 Sportster 55 OHV FSM pg 5F-1

photo by Pablo83 of the XLFORUM

https://www.xlforum.net/forum/sportster-motorcycle-forum/sportster-motorcycle-era-specific-and-model-s

2024/01/01 17:28 9/11 IH: Engine Control - Sub-01A

```
pecific/ironhead-sportster-motorcycle-talk-1957-1985/144683-magneto-ch-porn-thread/page7?threadid=1569256&page=7
```

photo by Ozark of the XLFORUM

https://www.xlforum.net/forum/sportster-motorcycle-forum/sportster-motorcycle-era-specific-and-model-specific/ironhead-sportster-motorcycle-talk-1957-1985/92341-just-picked-up-a-1960-basket-

case/page2#post1921155

- '

photo by savagegarden of the XLFORUM

https://www.xlforum.net/forum/sportster-motorcycle-forum/sportster-motorcycle-era-specific-and-model-specific/ironhead-sportster-motorcycle-talk-1957-1985/172193-advantages-of-using-amagneto?t=1844816

(د

needspeed of the XLFORUM

https://www.xlforum.net/forum/sportster-motorcycle-forum/sportster-motorcycle-era-specific-and-model-specific/ironhead-sportster-motorcycle-talk-1957-1985/190797-1968-xlch-900-timing-question?t=2033659&highlight=circuit+breaker

rivethog of the XLFORUM

https://www.xlforum.net/forum/sportster-motorcycle-forum/sportster-motorcycle-era-specific-and-model-specific/ironhead-sportster-motorcycle-talk-1957-1985/178207-69-dual-plug-heads-with-

timer/page4?t=1916320&page=4

8)

photos by 1957xler of the XLFORUM

https://www.xlforum.net/forum/sportster-motorcycle-forum/sportster-motorcycle-era-specific-and-model-specific/ironhead-sportster-motorcycle-talk-1957-1985/171998-valve-timing-off?t=1844586 $\frac{11}{12}$ $\frac{12}{13}$

57-69 HD Sportster FSM pg 5F-2

needspeed of the XLFORUM

https://www.xlforum.net/forum/sportster-motorcycle-forum/sportster-motorcycle-era-specific-and-model-specific/ironhead-sportster-motorcycle-talk-1957-1985/187639-timing-180-deg-out?t=2003348 $^{\tiny 15)}$ $^{\tiny 18)}$

Ferrous Head of the XLFORUM

https://www.xlforum.net/forum/sportster-motorcycle-forum/sportster-motorcycle-era-specific-and-model-specific/ironhead-sportster-motorcycle-talk-1957-1985/187639-timing-180-deg-

out/page2?t=2003348&page=2

16)

doodah man of the XLFORUM

https://www.xlforum.net/forum/sportster-motorcycle-forum/sportster-motorcycle-era-specific-and-model-specific/ironhead-sportster-motorcycle-talk-1957-1985/187639-timing-180-deg-out/page2?t=2003348&page=2

17)

Sadsack of the XLFORUM

https://www.xlforum.net/forum/sportster-motorcycle-forum/sportster-motorcycle-era-specific-and-model-specific/ironhead-sportster-motorcycle-talk-1957-1985/187639-timing-180-deg-

```
out/page2?t=2003348&page=2
```

photo by The Doctor71 of the XLFORUM

https://www.xlforum.net/forum/sportster-motorcycle-forum/sportster-motorcycle-era-specific-and-model-specific/ironhead-sportster-motorcycle-talk-1957-1985/187639-timing-180-deg-out?t=2003348

video by Shadowdog500 of the XLFORUM https://www.youtube.com/watch?v=mKVh4pbyh2A

Article by Hopper of the XLFORUM

https://www.xlforum.net/forum/sportster-motorcycle-forum/sportster-motorcycle-era-specific-and-model-specific/ironhead-sportster-motorcycle-talk-1957-1985/24033-setting-the-ignition-timing-on-your-

```
ironhead/page11?page=11&t=39764
```

```
24) 25) 26) 28) 29) 30) 31) 32)
```

photo by Hopper of the XLFORUM

https://www.xlforum.net/forum/sportster-motorcycle-forum/sportster-motorcycle-era-specific-and-model-specific/ironhead-sportster-motorcycle-talk-1957-1985/24033-setting-the-ignition-timing-on-your-ironhead/page11?page=11&t=39764

doodah man of the XLFORUM

https://www.xlforum.net/forum/sportster-motorcycle-forum/sportster-motorcycle-era-specific-and-model-specific/ironhead-sportster-motorcycle-talk-1957-1985/194724-static-timing-identifying-wide-small-cam-lobes?t=2071019&highlight=circuit+breaker

Hopper of the XLFORUM

https://www.xlforum.net/forum/sportster-motorcycle-forum/sportster-motorcycle-era-specific-and-model-specific/ironhead-sportster-motorcycle-talk-1957-1985/24033-setting-the-ignition-timing-on-your-ironhead/page12?t=39764&page=12

70-78 HD Sportster FSM pg 5-30

70-78 HD Sportster FSM pg 5-35

HD Service Bulletin #562A dated May 1, 1969 pg OC-261

37) 38) 40) 42

Dr Dick

https://www.xlforum.net/forum/sportster-motorcycle-forum/sportster-motorcycle-era-specific-and-model-specific/ironhead-sportster-motorcycle-talk-1957-1985/112326-a-photo-catalog-of-ironhead-

```
parts/page22?t=1062720&page=22
```

43) 44)

1954-1978 HD Sportster Parts Catalog pg 45

1954-1978 HD Sportster Parts Catalog pg 47

photo by Dr Dick

 $https://www.xlforum.net/forum/sportster-motorcycle-forum/sportster-motorcycle-era-specific-and-model-specific/ironhead-sportster-motorcycle-talk-1957-1985/112326-a-photo-catalog-of-ironhead-parts/page22?t=1062720\&page=22 \\ ^{47)}$

photos by Dr Dick

https://www.xlforum.net/forum/sportster-motorcycle-forum/sportster-motorcycle-era-specific-and-model-specific/ironhead-sportster-motorcycle-talk-1957-1985/112326-a-photo-catalog-of-ironhead-parts/page22?t=1062720&page=22

2024/01/01 17:28 11/11 IH: Engine Control - Sub-01A

From:

http://www.sportsterpedia.com/ - Sportsterpedia

Permanent link:

http://www.sportsterpedia.com/doku.php/techtalk:ih:engctl01a

Last update: 2023/12/31 17:31

