

Table of Contents

REF: Oiling & Lubrication	1
Transmission \ Primary Oil	1
<i>About JASO Certifications</i>	1
Transmission / Primary Oil Capacities	1
When to Check/ Change Transmission Fluid	2

[Go To Technical Menu](#)

REF: Oiling & Lubrication

Transmission \ Primary Oil

About JASO Certifications

- JASO introduced the MA and MB oil specification to distinguish between friction modified and non friction modified engine oils. Most four-stroke motorcycles with wet clutches need a JASO MA oil. ¹⁾
- The JASO MA - MB range:

	JASO MA	JASO MB
Dynamic Friction Characteristic Index (DFI)	≥1.45 and <2.5	≥0.5 and <1.45
Static Friction Characteristic Index (SFI)	≥1.15 and <2.5	
Stop Time Index (STI)	≥1.55 and <2.5	≥0.5 and <1.55

- The JASO MA range is further divided into 2 distinct ranges - JASO MA1 and JASO MA2:

	JASO MA1	JASO MA2
Dynamic Friction Characteristic Index (DFI)	≥1.45 and <1.8	≥1.8 and <2.5
Static Friction Characteristic Index (SFI)	≥1.15 and <1.7	≥1.7 and <2.5
Stop Time Index (STI)	≥1.55 and <1.9	≥1.9 and <2.5

Transmission / Primary Oil Capacities

1957-1990 ^{2) 3) 4) 5)}	1.5 pints (24 oz) (710 ml)
1991-1992 ⁶⁾	40 ounces (1183 ml)
1993-1996, 1998, 2004 ^{7)8) 9) 10)}	32 oz (946 ml)

- Discrepancy in the 1991 FSM. It shows 1.5 pints of oil for primary / transmission. ¹¹⁾ 1991-1992 FSM corrected the 1991 book showing 40 oz for both years. ¹²⁾
- Note that for 1994-later, the manual says "Verify that lubricant level is even with bottom of clutch diaphragm spring." Not higher or lower, but even with the diaphragm spring. It also includes this warning: "Do not overfill the primary chaincase with lubricant. Overfilling may cause rough clutch engagement and incomplete disengagement (or clutch drag)."

When to Check/ Change Transmission Fluid

HD Transmission Oil Recommendations	Check Change Only If Needed	Change
1959-1978 ^{13) 14)}	Every 1,000 miles	Every 5,000 miles or 1 year, Every Spring or Fall
1979-1985 ¹⁵⁾		After first 500 miles, Every 5,000 miles, Spring or Fall
1986-2003 ^{16) 17)18)}	After first 3,000 miles, Every 2,500 miles after oil changes	After first 500 miles Every 5,000 miles after
2004 ¹⁹⁾		After first 1,000 miles, At first 5,000, Every 5,000 miles after

Go To Technical Menu

1)

<http://www.oilspecifications.org/jaso.php>

2)

1959-1969 HD Sportster FSM pg 1A-3

3)

1970-1978 HD Sportster FSM pg 1-1

4)

1979-1985 HD Sportster FSM pg 2-1

5)

1986-1990 HD Sportster FSM pg 2-1

6) ¹²⁾

1991-1992 HD Sportster FSM pg 2-1

7)

1993-1994 HD Sportster FSM pg 2-1

8)

1995-1996 HD Sportster FSM pg 2-1

9)

1998 HD Sportster FSM pg 2-1

10)

2004 HD Sportster FSM pg 2-1

11)

1991 HD Sportster FSM pg 2-1

13)

1959-1969 HD Sportster FSM pg 1B-6

14)

1970-1978 HD Sportster FSM pg 1-5

15)

1979-1985 HD Sportster FSM pg 1-2

16)

1986-1990 HD Sportster FSM pg 1-2

17)

1991-1992 HD Sportster FSM pg 1-2

18)

1993-1994 HD Sportster FSM pg 1-2

19)

2004 HD Sportster FSM pg 1-7

From:

<http://www.sportsterpedia.com/> - **Sportsterpedia**

Permanent link:

<http://www.sportsterpedia.com/doku.php/techtalk:ref:oil02>

Last update: **2018/07/23 14:42**

