## 2008 Touring ACR Wire Harness Kit

A small number of 2008 Automatic Compression Release wire harness kits (70623-08) were assembled with the incorrect wire terminal attached to the Violet/Gray wire. This is the wire that installs in the ECM at socket 19. This kit is only used on 2008 Touring models. The correct terminal is part # 72605-08. The correct socket terminal can be identified by its gold color. If you have one of these kits with the wrong terminal, simply replace the terminal with the correct part.