

Table of Contents


REF: Body Parts - Sub-30N 3

[Go To Technical Menu](#)

REF: Body Parts - Sub-30N

Homemade floorboards ¹⁾

These are pretty simple to make.
The boards are fabbed from scrap aluminum.



A short piece of square stock (scrap re-purposed here) with one corner flattened at a 45° for the peg mounts.

Two holes drilled and tapped for each board.



Go To Technical Menu

1)

photos by beuz of the XLFORUM

<https://www.xlforum.net/forum/sportster-motorcycle-forum/sportster-motorcycle-accessories/85646-footpegs-to-floor-boards?t=657100>

From:

<https://sportsterpedia.com/> - **Sportsterpedia**

Permanent link:

<https://sportsterpedia.com/doku.php/techtalk:ref:body30n>

Last update: **2024/01/09 21:34**

