

Table of Contents

REF: Tools - 162 3

Pushrod Tubes 3

91-Up 3

[Go To Technical Menu](#)

REF: Tools - 162

Pushrod Tubes

91-Up

A standard Allen wrench can be used to remove or install the tube base bolts.

But it won't help to properly torque the bolts on installation.

A short Allen wrench adapter, short extension and a 3/8" socket wrench works well for removing / installing the bolts.

The short Allen adapter and extension brings the wrench to the smaller OD area of the tube. A beam type torque wrench with a small head will then work for proper torque on the bolts. ¹⁾

[Go To Technical Menu](#)

¹⁾

photos by Hippysmack

From:

<http://www.sportsterpedia.com/> - **Sportsterpedia**

Permanent link:

<http://www.sportsterpedia.com/doku.php/techtalk:ref:tools162>

Last update: **2019/04/08 17:25**



