


### 2007 Touring Model PDI Manual and Accessory Fuse

In the 2007 Touring model PDI manual on page 2-2, under "Installing Fuel Pump Fuse", it instructs you to remove the spare fuse and install it in the fuel pump fuse location. This is incorrect and should read: Remove the 15-amp fuel pump fuse located in the P&A fuse slot of the fuse-block located under the right side cover, and install it in the fuel pump fuse location. Please correct your manuals to reflect this change.

The fuel pump fuse is located in the P&A slot when you receive the motorcycle.



The accessory fuse on 2007 Touring models has been moved to the EFI fuse block, located under the right hand side cover. We are correcting I-Sheets to reflect this change as we find errors but be advised some may contain outdated information.

P&A fuse location

