

SOFTAIL REPLACEMENT FUEL TANKS PRIME OR PAINTED

All Softail replacement fuel tanks, prime or painted, 2001 and later will now come with the 2008 style welded fuel level sender mounting channel in the center of the tank, shown below in **Figure 1**.

Painted fuel tanks will utilize the following prime part numbers:

61625-01D - All Softail models 2001 and later except Deuce

62082-00D - 2001 and later Deuce

All prime fuel tanks and replacement painted fuel tanks will also now be shipped with a fuel level sender adapter bracket kit 75307-07 with [I-sheet J04513](#), rev 2-1-07 shown below **Figure 2**.

This kit is NOT sold. If you received a replacement 2006-2007 fuel tank and this kit was not included, please contact your SPOC representative to obtain a kit.

2001 to 2005: The kit is not required; however it will ship with the fuel tank but will not be used. Fuel level sender will mount in its original configuration.

2006 and 2007: The adapter kit is only required for installation of the fuel level sender for these two years.

2008: The kit will not be used and fuel level sender will mount directly to welded in bracket.



Figure 1



Figure 2