

TT245 – June 19, 2006

### 19" Wheel Tubes

Beginning on March 21, 2006 production began using tube # 41339-06 on all 19" rims. With this change you will notice that the installation procedure for installing this tube in the 19" steel rim (Part # 43001-79) has also changed. The tube will come with a washer and nut already installed and an extra washer and nut. The rim will be between the nut and second washer; the second washer is installed with the convex side facing the rim. This will center the valve stem in the rim hole. See the picture below.



The washer is **not** used on the Profile rim (Part # 43570-06) as this rim has a smaller valve stem hole.